

# Optimization of a Drone-based System for Instrumental Odour Monitoring using Feature Selection


A Benegiamo, J. Burgués, J. Alonso-Valdesueiro, B.J. Losetierre,  
L. Terren, L. Saucó, M.D. Esclapez, S. Doñate, A. Gutiérrez, **S. Marco**

# Environmental Odour Monitoring

- Odour pollution is a major cause of citizen complaints. Waste processing plants often are sources of malodours.
- The reference method to estimate odour concentration is Dynamic Olfactometry (EN13725-2022).
  - Infrequent
  - Limited locations
  - Expensive
- Instrumental Odour Monitoring Systems (IOMS) may be an option to have continuous odour monitoring.



- Odour is not objective: it is a human perception.
- Malodours are complex mixtures with hundreds of compounds that can contribute to the overall odour perception
- Odours can sometimes be due to minor components in the presence of odourless major components
- Emissions of plants can vary in time due to many factors: e.g. the quality of the water intake.
- The reference method (Dynamic Olfactometry) features multiplicative errors with a factor of 2 (95% CI)




Generated by DALLE

- Usually IOMS are mounted in fixed locations.
- **SNIFFIRDRONE GOAL:**
  - Real time odour concentration estimation with an IOMS flying on a drone
  - 4 Waste Water Treatment Plants
  - 1 Composting plant
  - **Novelty:**
    - Drone operation
    - Calibration in flight conditions with transient signals.



# RHINOS Electronic nose



	Technology	Range	Accuracy	Response time ( $T_{90}$ )
Temperature	Integrated	-40 to +85°C	± 1°C	<2 s
Humidity	Integrated	0 to 100% RH	± 3% RH	<2 s
Pressure	Integrated	30 to 110 kPa	± 0.1 kPa	<2 s
Flow rate	Ultrasonic	-33 to +33 L/min	± 3% m.v.	<1 s
CO <sub>2</sub>	NDIR	0 to 5000 ppm	± 100 ppm	<60 s
CO	Electrochemical	0 to 100 ppm	± 0.5 ppm	<20 s
H <sub>2</sub> S	Electrochemical	0 to 20 ppm	± 0.1 ppm	<20 s
NH <sub>3</sub>	Electrochemical	0 to 100 ppm	± 0.5 ppm	<90 s
SO <sub>2</sub>	Electrochemical	0 to 20 ppm	± 0.1 ppm	<45 s

Sensor	Model	Target gases	Heater voltage
M1	TGS 2600	H <sub>2</sub> , CO, Ethanol	1.6 V
M2	TGS 2600	H <sub>2</sub> , CO, Ethanol	3.2 V
M3	TGS 2600	H <sub>2</sub> , CO, Ethanol	4.0 V
M4	TGS 2600	H <sub>2</sub> , CO, Ethanol	4.9 V
M5	TGS 2602	H <sub>2</sub> S, NH <sub>3</sub> , Toluene	1.6 V
M6	TGS 2602	H <sub>2</sub> S, NH <sub>3</sub> , Toluene	3.2 V
M7	TGS 2602	H <sub>2</sub> S, NH <sub>3</sub> , Toluene	4.0 V
M8	TGS 2602	H <sub>2</sub> S, NH <sub>3</sub> , Toluene	4.9 V
M9	TGS 2611	CH <sub>4</sub> , Hydrocarbons	1.6 V
M10	TGS 2611	CH <sub>4</sub> , Hydrocarbons	3.2 V
M11	TGS 2611	CH <sub>4</sub> , Hydrocarbons	4.0 V
M12	TGS 2611	CH <sub>4</sub> , Hydrocarbons	4.9 V
M13	TGS 2620	Alcohols, ketones	1.6 V
M14	TGS 2620	Alcohols, ketones	3.2 V
M15	TGS 2620	Alcohols, ketones	4.0 V
M16	TGS 2620	Alcohols, ketones	4.9 V

J. Burgués et al., Remote Sensing, 2021


J. Burgués et al. iScience, 2021

J. Burgués et al. Sci. Tot. Environ., 2022

- Methods
  - The waste-water treatment plant (WWTP) & 2020 measurement campaign
  - Signal and data processing workflow
  - Model training & Validation: Array optimization by Feature Selection
- Results
  - Raw signals
  - PLS full model and Variable Importance in Projection
  - Array optimization by Feature Selection
  - Model Comparison
- Summary




# Wastewater treatment plant & Meas. campaign



**Table 2.** Number of samples collected in each source during the four measurement days.


Day	Date	Settler ▲	Bioreactor ▲	Pretreatment ▲	Chimney ▲	Total (odour)	Blanks	Total
1	24/06/2020	3	3	2	2	10	7	17
2	25/06/2020	2	2	2	2	8	6	14
3	14/07/2020	3	3	3	3	12	11	23
4	15/07/2020	3	3	3	3	12	7	19
<b>Total</b>		11	11	10	10	42	31	73









# Example to raw signals




Pattern is formed by the concatenation of 5 min window centered around the odour sampling period.



- PLS LV=2, Model External Validation (N=40)




- Variable Importance




- Optimization was based on Nested Sequential Forward Selection using Interval Partial Least Squares (iPLS).


Minimum RMSECV error



Minimum RMSECV error



## Optimal Model



## Multiplicative Errors – Correlation Coeff.

Array Configuration	95% Conf	R
Full model	(0.2x-5.0x)	0.81
NH <sub>3</sub> TGS2602 @ 4V TGS2611 @ 1.6V	(0.3x -3.4 x)	0.89

N=40 samples

- IOMS on a flying drone provides odour concentration estimation based on transient sensor signals acquired in flying conditions.
- We have used a single model for all the odour sources.
- Full model provides unbiased predictions with 95% CI errors of a factor of 5x.
- After the optimization, the sensor array uses an EC  $\text{NH}_3$  sensor and two MOX sensors.
- The reduced system still provides unbiased predictions, and the error has been reduced to a factor 3.4x-
- The validity of these results is limited by the duration of the study and the use of a single WWTP.



# iSOCS Short Course Winter 2024 – Bormio, 15-19 January

## CHEMICAL SENSING FOR BIOMEDICAL APPLICATIONS: FROM A PROOF OF CONCEPT TO A MEDICAL DEVICE

### This Short Course will cover topics including:

- Sampling, storage and analysis of biological fluids
- Technological challenges and data processing related to multivariate chemical sensing
- Scientific and clinical validation of biomedical technologies
- Design of clinical validation trials
- Certification of biomedical devices
- Specific challenges related to healthcare applications (e.g., biocompatibility, cross contamination, etc.)
- Examples of technologies based on chemical sensing that became medical devices

### Speakers including:

- Prof. Raffaele Dellaca', Politecnico di Milano
- Prof. Santiago Marco, IBEC Barcelona
- Prof. Fabio Di Francesco, University of Pisa
- Prof. Corrado Di Natale, University of Rome Tor Vergata
- Prof. Anne-Claude Romain, University of Liège
- Prof. Dr. Med. Sascha Kreuer, Saarland University Medical Center
- Dr. Jan Mitrovics, JLM Innovation GmbH, Germany
- Dr. Alessandro Gobbi, Restech, Italy



**[www.olfactionsociety.org](http://www.olfactionsociety.org)**

[www.olfactionsociety.org/event/wintercourse2024](http://www.olfactionsociety.org/event/wintercourse2024) (coming soon)